



Fig.	Description	Part No. LP 37 E
1	Jaw	SK 1489 Z
2	Jaw Spring	SK 847
3	Jaw Pivot	SK 2106-67
4	Locking Bar	SK 3205-06
5	Lock Bar Bolt	SK 3221-01
6	Release Lever	SK 3105-18
7	Operating Handle	SK 3105-15
8	Head Bolt	SK 1513
9	Double Tension Spring	SK 3105-20
10	Wear Ring Fixture	SK 2105-19
10a	Wear Ring Fixture	SK 3105-93
11	Wear Ring Bolt	SK 2121-07
11b	Wear Ring Insert	SK 3105-92
11a	Wear Ring Bolt	SK 3121-55
12	Swivel Pin	SK 3104-05
13	Pedestal Bush	SK 2905-20
13a	Collar	SK 3105/95
14	Swivel Pin Bolt	SK 3121-28
15	Swivel Pin Plug	JS 1101-12
16	Spring Latch	SK 3121-52
17	Bolt for Spring Latch	SK 3521-03
18	Spring for Latch	SK 3121-59

Fig.	Description	Part No. LP 37 E
19	Adjusting Screw	SK 3105-97
20	Hex Nut	SK 2121-78
21	Guide Piece	SK 3205-07
22	Eye Bolt Complete	SK 2122-04
23	Grease Line Complete	SK 3108-02
24	Operating Handle	SK 3105-15
26	Handle Extension	SK 3105-113
27	Internal Operating Handle	SK 3105-115
28	Head Bolt	SK 1513
29	Extended Handle Bolt	SK 2421-50
30	Cable Extension	SK 3521-02
31	Ball bearing	KDL 900-6W
32	Half Moon c/w 130mm Ped.	SK 3704-02
33a	Base plate (12mm) incl.56,57,58	SK 3706-12
33b	Base plate (16mm) incl.56,57,58	SK 3706-16
33c	Base plate (20mm) incl.56,57,58	SK 3706-20
34	Hex. bolt compl.	SK 3721-04
35	Countersunk bolt compl.	SK 3721-05
36	lock out pin compl.	SK 3706-10
37	Tube park	SK 3706-04
38	Tube lock out	SK 3706-05

Fig.	Repair Kits	Part No
1,2,3	Repair kit for locking device	SK 3221-52 Z
12,13,13a,14,15	Repair kit for locking device	SK 3121-061
1,2,3,8,11,23,28	Repair kit for locking device	SK 3121-060 Z
10,11,11a	Repair kit for wear ring	SK 3105-94 Kit