## Wear Limit Gauge King Pin Gauge

Above item is designed as a NO GO wear limit indicator, for either 50mm or 90mm king pins.

Once king pin can pass through gauge the king pin must be replaced. Also designed to check king pin protrusion.

Part number: JOSTGAUGEKINGPIN

